

TOOLS NEEDED -

- Gloves
- Utility knife
- Paper ruler or tape measure
- 2x4 piece of wood Protective eyeware
- Long-sleeved shirt

- Staple gun and staples
- Screwdriver
- Canned foam
- Cardboard sheet to cut insulation on

THE REAL PROPERTY OF THE REAL

4

2

3

6

5

3

Johns Manville A Berkshire Hathaway Company

MEET RECOMMENDED R-VALUES

R stands for resistance to heat flow. The higher the R-Value, the greater the insulation power. As R-Value increases, so does energy efficiency and home comfort. The colder or warmer the climate, the higher R-Value needed to maintain energy efficiency and comfort.

Zone	Attic	2x4 Walls	2x6 Walls	Floors	Crawl- spaces
7	R49 – R60	R13 – R15	R13 – R21	R25 – R30	
6					
5	R38 – R60				
4					
3	R30 – R60			R-26	R19 – R25
2	R38 – R49			R-13	R13 – R19
1					