

- INSTALLATION OF EXPAND-O-GARD SHOULD BEGIN AT THE FOUNDATION AND MOVE UPWARD, IN ORDER TO ENSURE PROPER WEATHER TIGHT SPLICES. SEE STEP 3 FOR ADDITIONAL INFORMATION.
- THE ADHESIVE AND URETHANE SEALANT INCLUDED IN THE CARTON ARE FOR SPLICING SECTIONS OF EXPAND-O-GARD DURING INSTALLATION.
- IF AN ADVANCED INSTALLATION METHOD IS REQUIRED FOR EXPAND-O-GARD SPLICES, ADHESIVE AND URETHANE SEALANT CAN BE PROVIDED BY JOHNS MANVILLE AT AN ADDITIONAL COST.
- FASTENERS ARE THE RESPONSIBILITY OF THE INSTALLING CONTRACTOR. FASTENER SHOULD BE RUBBER GROMMETTED OR EMBEDDED IN SEALANT TO PREVENT WATER PENETRATION.
- THE BUILDING SURFACE TO WHICH THE EXPAND-O-GARD IS TO BE INSTALLED SHOULD BE SMOOTH, CLEAN AND FREE OF ANY DIRT AND DEBRIS.

DRAWING NO.	SCALE	ISSUE DATE	REV. NO.	
INST-EOG-F	NTS	5/14/12		
PAGE 1	CAD FILE	CAD FILE:		
	EOG IN	EOG INSTALLATION INSTRUCTIONS.DWG		

EXPAND-O-GARD (STYLE F) INSTALLATION INSTRUCTIONS

Johns Manville is a Manufacturer of commercial rooling products and offers this general conceptual information to you as a courtesy. This complimentary assistance is not to be used or relied upon by anyone as a substitute for professional engineering design and documentation required by building code, contract, or applicable law. By accepting these comments you agree they do not constitute any representations, endorsements of, or an assumption by Johns Manville of any liability for either the adequacy of the design of this building or any other material not supplied by Johns Manville.

