

## **GoBoard® Waterproof Tile Installation Materials**

The GoBoard Installation Instructions / Technical Data Sheet approves two material types for joints and fastener locations sealing to achieve a waterproof tile installation: *polymer sealant/caulk* (in tube); and 2" wide polymer-coated alkali-resistant fiber glass mesh tape and mortar coated with a *liquid waterproofing membrane*.

Johns Manville does not recommend the use of specific brands, but the following are of the proper material types and tested to comply with ANSI A118.10 when used in combination with GoBoard, GoBoard LT and GoBoard Pro. **We do not recommend the use of self-leveling, latex or silicone based sealants.**

### **Polymer Sealants/Caulks:**

- *GoBoard® Pro Sealant* is the preferred sealant and adhesive for all GoBoard products and qualifies for the 10 year limited warranty when used in combination with GoBoard Fasteners or GoBoard Washers per manufacturer's installation instructions.
- *OSI® Quad® Max* (Model 1868684, 1893977)
- *DAP DynaFlex® 800* (Model 80800)
- *DAP 3.0™* (Model 18360)
- *Rapid Set® Non-Sag Sealant* (Model 196330010)
- *White Lightning® Optima™ White Premium Hybrid Sealant* (Model W31200010)
- *KBRS Showerseal® Polyurethane Sealant*
- *QUIKRETE® Advanced Polymer Non-Sag Sealant* (Model 866011)
- *SikaBond® Construction Adhesive* (Model 106403)
- *Liquid Nails® Fuze-It®* (Model LN-2000) – More of an adhesive, cures harder with less flexibility

### **Liquid Waterproofing Membranes:**

- *MAPEI- Mapelastic AquaDefense Waterproofing and Crack-Isolation Membrane*
- *TEC®* – Waterproof & Crack Prevention Membrane
- *Custom Building Products - RedGard® Waterproofing and Crack Prevention Membrane*
- *KBRS – ShowerSeal® Seamless Liner*
- *Laticrete – Hydro Ban®*

**View the Complete Installation Instructions / Technical Data Sheet:**  
**[www.JM.com/GoBoard](http://www.JM.com/GoBoard)**