

## NOTES:

- 1. REFER TO JOHNS MANVILLE WEBSITE (www.jm.com) FOR MOST UP-TO-DATE INFORMATION.
- 2. PLEASE SEE SINGLE PLY FLASHING SPECIFICATIONS FOR A FULL DESCRIPTION OF INSTALLATION INSTRUCTIONS AND REQUIREMENTS WHICH ARE CONSIDERED A PART OF THIS DETAIL.
- 3. ANY CARPENTRY OR METAL WORK SHOULD BE DESIGNED AND CONSTRUCTED IN ACCORDANCE WITH LOCAL CODE REQUIREMENTS AND/OR PROJECT SPECIFICATIONS. THESE COMPONENTS SHOULD BE REVIEWED AND APPROVED BY A LICENSED DESIGN PROFESSIONAL.
- 4. REFER TO JM PERMA-TITE COPING INSTALLATION INSTRUCTIONS FOR PROPER FASTENING REQUIREMENTS.
- 5. JM PVC EDGE SEALANT IS OPTIONAL ON CUT OR NON ENCAPSULATED EDGES OF PVC REINFORCED MEMBRANE. THIS INCLUDES FACTORY CUT MEMBRANE.

## PFW-T4 FLASHING WALL SCALE N.T.S PERMA-TITE CONTINUOUS CLEAT COPING SYSTEM OVER PVC MEMBRANE TYPE: JM PVC JOHN MAXIMUM GUARANTEE TERM: 30 YEAR JOHN MAXIMUM GUARANTEE TERM: 30 YEAR JOHN MAXIMUM GUARANTEE TERM: 30 YEAR PERMA-TITE CONTINUOUS CLEAT COPING SYSTEM OVER PVC MEMBRANE TYPE: JOHN Manville is a manufacturer of commercial roofing products and offers this general conceptual information to you as a courteys. This complimentary assistance is not to be used or relied upon by anyone as a substitute for professional engineering design and documentation required by building code, contract, or applicable law. By accepting these comments you agree they do not constitute any representations, endorsements of, or an assumption by Johns Manville of the design of this building or any other material not supplied by Johns Manville. Johns Manville