

BATTS AND ROLLS

What you need to get started on your insulation project.




TOOLS NEEDED

- Gloves
- Utility knife
- Paper ruler or tape measure
- 2x4 piece of wood
- Protective eyewear
- Long-sleeved shirt
- Cardboard sheet to cut insulation on
- Caulk
- Attic light
- Canned foam
- Staple gun and staples
- Kneepads
- Screwdriver
- Mask



MEET RECOMMENDED R-VALUES

R stands for resistance to heat flow. The higher the R-Value, the greater the insulation power. As R-Value increases, so does energy efficiency and home comfort. The colder or warmer the climate, the higher R-Value needed to maintain energy efficiency and comfort.



| Zone | Attic | 2x4 Walls | 2x6 Walls | Floors | Crawl-spaces |
|------|-----------|-----------|-----------|-----------|--------------|
| 7 | R49 – R60 | R13 – R15 | R13 – R21 | R25 – R30 | |
| 6 | | | | | |
| 5 | | | | | |
| 4 | R38 – R60 | | | R-26 | R19 – R25 |
| 3 | | | | | R30 – R60 |
| 2 | R38 – R49 | | | R-13 | |
| 1 | | | | | |

