



ASSEMBLY

- ① MASK TARGET AREA ON ROOF MEMBRANE.
- ② CLEAN & PRIME ALL NON-POROUS AREAS (METAL, ETC.) REQUIRING LIQUID MEMBRANE WITH PERMAFLASH PRIMER.
- ③ APPLY 30 MIL. BASE COAT OF MBR FLASHING CEMENT WITHIN TARGET AREA. (A BRUSH WORKS BEST).
- ④ EMBED SCRIM(S) INTO WET BASE COAT OF MBR FLASHING CEMENT, 1/2" SHORT OF TARGET AREA.
- ⑤ IMMEDIATELY AFTER EMBEDDING THE SCRIM, APPLY 60 MIL. FINISH COAT OF MBR FLASHING CEMENT OVER SCRIM AND 1/2" BEYOND, ENSURING SCRIM IS COMPLETELY EMBEDDED.
- ⑥ REMOVE MASKING TAPE IMMEDIATELY AFTER APPLICATION OF FINISH COAT.

WALL SURFACE
FINISH COAT OF MBR FLASHING CEMENT (APPLIED 1/2" BEYOND SCRIM OUTLINE)

PERMAFLASH SCRIM SET IN MBR FLASHING CEMENT

CREASE MEMBRANE

TERMINATE CAP SHEET AT 4" ABOVE ROOF-WALL

6"

1/2"

1/2"

* X

①

①

③

④

⑤

①

SCRIM OUTLINE

MASK TARGET AREA FOR APPLICATION

ROOF MEMBRANE

NOTES:

- A. AN EXTRA COAT OF MBR FLASHING CEMENT MUST BE PLACED BETWEEN SCRIM LAYERS WHERE THEY OVERLAP TO ENSURE A PROPER BOND.
 - B. REFER TO PERMAFLASH APPLICATION INSTRUCTIONS FOR GENERAL GUIDELINES REGARDING THE PERMAFLASH SYSTEM.
- * "x" DIMENSION DEPENDANT UPON APPLICATION.

DRAWING NO.		PERMAFLASH STANDARD BASE FLASHING DETAIL		
PMF-10				
SCALE	ISSUE DATE	MAXIMUM GUARANTEE TERM:		
N.T.S	5-1-17			