



JM QUICKFOAM® ADHESIVE

TWO-PART LOW-RISE POLYURETHANE ADHESIVE

SPEED + PERFORMANCE

POWERFUL RETRACTION

*Sleek, low-profile finish with no post-rise, ensuring a smooth application with minimal ballasting.**

STRENGTH MEETS FLEXIBILITY

Designed to endure, QuickFoam™ offers exceptional strength, while remaining flexible once cured.

COVER MORE, USE LESS

QuickFoam® Adhesive is approved for adhering 4'x8' polyiso insulation and cover boards. Specific installation procedures are required.†

WALK AND ROLL

Forget about traditional ballasting — just apply, walk it in, roll it and let the bond do the rest.*

EXCELLENT GREEN STRENGTH

With exceptional initial bonding power, it holds materials firmly in place, even before full curing.††



SCAN HERE FOR MORE INFO


NO POST-RISE



FLEXIBLE WHEN CURED



MINIMAL BALLAST TIME



CODES AND APPROVALS



APPROVED



*Minimal Ballasting is defined as: rolling insulation boards or membrane with a 150 lb roller within 5-7 minutes from initial application of QuickFoam. Boards may be temporarily weighted or relief-cut where necessary to keep them in constant contact until the adhesive cures. Traditional Ballasting is defined as: weighing insulation boards down with readily available load on the rooftop; examples include pails of bonding adhesive, screw/plate buckets or other sources of weight (minimum 32 lbs) that will not damage roof insulation.

**QuickFoam™ can be applied down to 0.50 gallon per 100 ft² compared to 1.1 gallons per 100 ft² with beads 4" o.c. QuickFoam™ offers up to a 10% increase in coverage over existing Spatter applications with JM low-rise foams based on JM provided coverage rates for RSUA and QuickFoam. Coverage rates are approximate and may vary based on substrate type and application. Approved substrates include structural concrete decks, JM Vapor Barrier SA or SAR, ENRGY 3®, Protector HD®, RetroPlus, DuraBoard, Separator CGF, Securock, DensDeck, DensDeck Prime, DEXcell®, smooth modified asphalt membranes and granulated asphalt membranes. Please contact JM Technical Services for other approved substrates.

††Based on internal comparative testing of JM QuickFoam, 2-Part UIA, and RSUA low-rise foam adhesives. Green strength can be defined as the bond strength of an adhesive before it has fully cured and reached its final ultimate tensile strength. This strength is usually considerably lower than the final ultimate bond strength.

†Specific installation procedures are required for 4'x8' board securement, please reference the JM QuickFoam Installation Guidelines for details.

FEATURES
& BENEFITS

ONE ADHESIVE, FULL SYSTEM USE

COMPATIBLE WITH SEVERAL APPLICATIONS

FLEECE BACK MEMBRANES

Approved in beads OR spatter for membrane, insulation, and cover board securement.


BOARD TO BOARD/DECK SECUREMENT

QuickFoam® Adhesive is approved for adhering 4'x8' ENRGY 3 Polyiso Insulation, ProtectoR HD, SeparatoR CGF, and all gypsum cover boards. Specific installation procedures are required, reference the QuickFoam®

Install Guide.*

VARIOUS SUBSTRATES

Polyisocyanurate; HD wood fiber; perlite; HD Polyiso; gypsum; concrete; treated plywood; cementitious wood fiber plank; base sheets; gypsum; and some existing smooth surfaced asphalt.



SMOOTH FINISH WITH RETRACTION TECHNOLOGY

QuickFoam® retracts as it cures, which reduces telegraphing and offers a smooth, clean appearance. This feature also reduces ballasting time; installations can simply be walked-in and rolled*.



VERY SEVERE HAIL APPROVED

With 50 approved VSH assemblies and counting, JM QuickFoam® systems withstand the harshest conditions over the long haul.



NO-SWEAT SWITCH

QuickFoam® adhesive is engineered for broad compatibility, working effectively with **all major spray rigs**. This exceptional versatility for contractors makes switching to QuickFoam® simple.

Reference JM QuickFoam® Installation Guidelines for a complete list of compatible spray equipment.

When switching products, JM recommends following equipment manufacturer's instruction's for purging existing material prior to switching to a different product.

Learn more about JM QuickFoam as well as our comprehensive portfolio of JM Adhesives at JM.COM/ROOFING

RS-9382 10-25 (Replaces 9-25)